



# Multicom Optical Micro-Node

## MUL-MN-1000D-5/42

User Manual v.6

### EXTERIOR INDICATOR LEDs




Figure 1 – Micro-Node

1. Power input +12~+15VDC
2. Down-stream RF output / up-stream RF input / power input (DC+12V)
3. Power ON LED display
4. Output power test point (1V/mW)
5. Up-stream RF input level test port (-20dB)
6. Up-stream laser output LED display
7. Up-stream fiber output
8. Down-stream RF output level test port (-20dB)
9. Down-stream fiber input
10. Input power test point (1V/mW)
11. Down-stream input power LED display
12. Set-screw grounding location
13. Mounting screw slot



# Multicom Optical Micro-Node

## MUL-MN-1000D-5/42

---

### OPERATION NOTICE

- Connect the optical input signal:
  - Inspect and clean the fiber strand optical connector. Using an Optical Power Meter, verify that the optical input signal is between -6 and + 3 dBm (0.25 to 2 mW).
    - Alternatively, connect the optical input and measure the DC voltage with respect to ground at the optical input test point (10). The voltage is approximately 1V/mW (between 0.25 and 2.0 V), for proper operation. At this time the LED "Optical Power" will be lit.
  - Using an RF Signal Meter, measure the RF Downstream Power Level Output (2). The output level should be approximately +25 dBmV per channel with an optical input of 0 dBm (+/- 2 dB RF for each 1 dB +/- optical input).
    - Alternatively, measure the RF Output at Downstream Level Test Port (8). The level at the test port will be approximately 20 dB below the actual RF output level.
  - Using an Optical Power Meter, measure the output of the Return Path Upstream Laser connector (7). The output power is a nominal 0 dBm (1 mW).
    - Alternatively, measure the DC Voltage at the Output Power Test Point (4) with respect to ground. The reading should be approximately 1.0 V (1.0V/mW).
  - Using an RF Signal Meter, verify the RF input to the Micro-Node is a nominal 20 dBmV. The measurement at RF Upstream Input Test Port (5) will be 20 dB below the actual input level.
- Use only Single Mode Fiber (SMF) optic cable (9/125 $\mu$ M). Multi-Mode Fiber (MMF) is incompatible with the equipment and will result in unacceptable performance and possible damage to the equipment.
- All fiber splices should be fusion-type splices. Avoid mechanical or compression type connections.
- For optimum performance, fiber runs should be made directly from the transmitter to the receiver. Minimize the use of adapters, patch panels, and additional points of failure and signal loss.
- In order to ensure return loss is maximized, use only SC/APC connectors. Clean and inspect connectors and fiber endfaces prior to installation, and every plug in/out cycle.
- Use only industry approved methods, materials, and solutions for cleaning.
- Do not turn on the node without a protector cover at the unit connector end, otherwise the laser can do harm, especially to eyes. This is especially critical because the laser is invisible.
- Always power off the node prior to making connections. Failure to do so may cause irreparable damage to the laser.

### WARRANTY AND REPAIR

The Multicom MUL-MN-1000D-5/42 has a one year warranty and is subject to Multicom's standard warrantee terms. There are no user serviceable components inside the unit. The warranty is void if the unit is opened or is damaged due to misuse.



# Multicom Optical Micro-Node

## MUL-MN-1000D-5/42

### PRODUCT SPECIFICATIONS

Down-stream Specifications		Values	Notes
Optical	Operating wavelength (nm)	1260 – 1620	
	Optical input (dBm)	-6 – +3	
	Return loss (dB)	>50	
	Input power test point (V/mW)	1	
	Connector	SC/APC	
RF	Max. operating bandwidth (MHz)	54 – 1000	
	Flatness (dB)	-0.5 – +0.5	54~1000 MHz
	Output return loss (dB)	16	54~1000 MHz
	Output level (dBmV)	25	Optical input at 0dB
	Output level test port (dB ref)	-20	
	Impedance ( $\Omega$ )	75	
	RF connector	F-female	
Link	CNR (dB)	52	78 CH, Optical input at 0dBm
	CTB (dB)	-65	
	CSO (dB)	-60	
	HUM (dB)	-60	
General	Power supply (Volts DC)	+12	
	Power consumption (W)	4	
	Operating temp. ( $^{\circ}$ C)	-20 – 65	-4 – 150 $^{\circ}$ F
	Storage temp. ( $^{\circ}$ C)	-40 – 85	
	Relative humidity (%)	5 – 95	
	Size (WxDxH in mm)	130x106x33	5¼ x 4¼ x 1¼ inches
Up-stream Specifications		Values	Notes
Optical	Rev. TX operating wavelength	1310	
	Type of laser with return path	FP	
	Output power (mW)	1.0	
	Return loss (dB)	>55	
	Output power test point (V/mW)	1	
	Connector	SC/APC	
RF	Operating bandwidth (MHz)	5 – 42	
	Flatness (dB)	-0.5 – +0.5	5~42MHz
	Noise power ratio (dB)	37	FP link loss $\geq$ 15dB
	Input level (dBmV)	20	
	Return loss (dB)	16 – 18	5~42MHz
	Input level test port (dB ref)	-20	



# Multicom Optical Micro-Node

## MUL-MN-1000D-5/42

### IMPORTANT SAFEGUARDS

Multicom strongly advises you to read the following safety instructions prior to installing and operating this equipment.

- **Read These Instructions First** – All safety and operating instructions should be read before installing or operating this equipment.
  - **Retain This User Manual** – Safety and operating instructions must be retained for future reference.
  - **Ventilation** – The Optical Micro-Node should be kept at a distance from other objects to keep from overheating. **Maximum operating ambient temperature is 150°F (65°C).**
  - **Power Sources** – The mains circuit should be a dedicated, unswitched supply. Keeps the unit away from high voltage or other interference creating devices such as motors, compressors, etc.
- ⚠ **CAUTION: For continued protection against risk of fire, replace circuit breakers/fuses (if necessary) with one of only the same type and rating.**
- ⚠ **Optical Output Safety: Optical Micro-Node units may emit harmful invisible laser radiation if powered on and the case is opened or the beam path is exposed.**



The Multicom MUL-MN-1000D-5/42 Optical Micro-Node is classified as Class 1M per IEC/EN 60825-1/A2:2001. This product complies with FDA/CDRH, 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50 dated 26 July, 2001.

Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers and microscopes) within a distance of 100 mm may pose an eye hazard.

Laser power up to 26 mW at 1310 nm could be accessible if optical connector is open or fiber is broken. Lasers are Powered ON whenever the unit is powered.

- ⚠ **CAUTION: Use of controls, adjustments, and procedures other than those specified herein may result in hazardous laser radiation exposure.**

**For support with and more information about the Multicom MUL-MN-1000D-5/42 Optical Micro-Node, please contact your Multicom representative:**

**www.multicominc.com | 800- 423-2594 | 407-331-7779**  
**1076 Florida Central Parkway, Longwood, FL 32750**